TD1 - Traitement d'image

Le but de cette séance est d'étudier les notions vues dans les chapitres 1, 2, 3 et 4 du cours : prétraitement, segmentation et mesures sur des objets.


Contents

- 3.1. Segmentation d'une image
- 3.2. Distribution granulométrique
- 3.3 Traitement de la séquence

3.1. Segmentation d'une image


Image Cailloux

```
clear all;
close all;
base='Images/prova6_226';
i=1;
nom=sprintf('%s_%03d.tif',base,i-1);
f=imread(nom);
figure(1),imshow(f);
```




Correction dérive de fond

```
s=strel('disk',30);
f1=imclose(f,s)-f;
figure(2),imshow(f1);
```




Binarisation

```
fbin=tse_imthreshold(f1,1,'entropy');
figure(3),imshow(fbin);
```




Séparation objets

```
fbin2=tse_imsplitobjects(fbin);
figure(4),imshow(fbin2);
```



${\bf Ouverture} \, + \, {\bf suppression} \, \, {\bf bords} \,$


```
s=strel('disk',1);
fbin3=imopen(fbin2,s);
fbin3=imclearborder(fbin3);
figure(5),imshow(fbin3);
```



3.2. Distribution granulométrique


Labelisation

```
[fe,n]=bwlabel(fbin3);
fe_rgb=label2rgb(fe);
figure(6),imshow(fe_rgb);
```



Mesures


```
mes=regionprops(fe,'EquivDiameter');
d=[mes.EquivDiameter];
% Conversion
d=d/size(f,1)*150;
% Histogramme
figure(7);
h=hist(d,1:ceil(max(d)));
bar(2:12,h(2:12));
```



3.3 Traitement de la séquence

```
base='Images/prova6_226';
h=zeros(11,15);
for i=1:15
   nom=sprintf('%s_%03d.tif',base,i-1);
   disp(nom);
   f=imread(nom);
   h(:,i)=distribution_taille(f,150,2:12);
```

```
end
h_cumule=sum(h,2);
figure(8);
bar(2:12,h_cumule);
Images/prova6_226_000.tif
Images/prova6_226_001.tif
Images/prova6_226_002.tif
Images/prova6_226_003.tif
Images/prova6_226_004.tif
Images/prova6_226_005.tif
Images/prova6_226_006.tif
Images/prova6_226_007.tif
Images/prova6_226_008.tif
Images/prova6_226_009.tif
Images/prova6_226_010.tif
Images/prova6_226_011.tif
Images/prova6_226_012.tif
Images/prova6_226_013.tif
Images/prova6_226_014.tif
```



Published with MATLAB® R2015b